


L. FM	L. EST. CASSA	L. PASS.	L. PORTA	L. MIN. EST. COP.	L. EST. COP.
700	677	606	615	786	822
800	777	706	715	886	922
850	827	756	765	936	972
900	877	806	815	986	1022
1000	977	906	915	1086	1122

H. FM	H. EST. CASSA	H. PASS.	H. PORTA	H. EST. MIN. COP.	H. EST. COP.
2150	2135	2099	2100	2190	2208

ATTENZIONE fornire sempre:

- le misure Foro Muro (L. FM. e H. FM.)
- le misure luce passaggio (L. PASS. e H. PASS.)

Le misure indicate sono espresse in millimetri



LINEA TERRA